Cutlery/utensil inserts

For 600-mm drawer width





ORGA-LINE inserts keep your cutlery organised and within easy reach every time. When setting the dinner table or entertaining outside, simply remove the required cutlery container and take it to the table. The stainless steel cutlery inserts are dishwasher safe, made for trouble free cleaning - "No more clutter."

Cutlery inserts in your Non Consumables



The Non-consumables zone is the largest storage zone in the kitchen whereby it holds items such as cutlery, crockery, glasses, plastic containers and electric whisks, among many others. For drawers with front width of 600 mm, use ORGA-LINE cutlery inserts like TI5 or BI1 and FI2 as they provide ample storage solutions without cluttering the interior of your drawers.



Cutlery inserts in the Cooking zone



The TI5 cutlery trays are best used in the Cooking zone to hold utensils that are utilised on a regular basis. As the drawer is located just near the knob, it will be easy for any kitchen user to access cooking utensils such as soup ladles, spatulas, forks, turners, skimmers or basting spoons just when you need them.