
AVENTOS HF

Ablum

Narrow aluminum frame door application

Lift mechanism set - Lift mechanism (qty 2) - #7 x 35 mm (1-3/8") wood screw (qty 8) Power factor Part no. 85 - 230 (1 lift mechanism req.) 20F2200.N5 231 - 470 20F2200.N5 471 - 880 20F2500.N5 780 - 1440 20F2800.N5

Cover set



- Right and left cover plate
- Non-handed cover cap (qty 2)

1401 - 2300 (3 lift mechanisms req.)


Colors: Light Gray, Dark Gray and Silk White

Part no.

20F2800.N5

Cover set 20F8020.NA

Telescopic arm set



Telescopic arm (qty 2)

 Cabinet heights
 Part no.

 479 (18-7/8") - 558 (22")
 20F3200.01

 558 (22") - 686 (27")
 20F3500.01

 686 (27") - 889 (35")
 20F3800.01

889 (35") - **1067** (42") **20F3900.01**

Narrow aluminum door hardware set

- 72T550A.TL CLIP top free swing narrow alum. top door hinge (gty 2)
- 78Z550AT CLIP top narrow aluminum bottom door hinge (qty 2)
- 175H3100 Top door mounting plate (qty 2)
- 175H5A00 Bottom door mounting plate (qty 2)
- 175H5B00 Telescopic arm mounting plate (qty 2)
- 669.110 Aluminum screw for the bottom door mounting plate, bottom hinge, top hinge and telescopic arm mounting plate (qty 18)

NOTE: Three hinges and mounting plates are required for cabinet widths over 1219 (48") or combined door weight of 26.5 lb.

Part no.

Narrow aluminum door hardware set
Installation screw for top mounting plate

78Z550ATA6

606N or 606P




AWARNING

Risk of injury from spring-loaded arm

- Do not push arm assembly down or leave in the down position.
- Remove mechanism before installing or removing cabinet.

1 Locating pin locations



TR = Top reveal **TDH** = Top door ht.

Top door height (TDH)	Y
231 to 271	TDH x .6 - 28 + TR
272 to 531	TDH × .6 - 57 + TR


Part no.


Universal individual template is available for pre-boring holes for locating pins.

65.1051.02

2 Attach the lift mechanism

Align the two locating pins on the lift mechanism with the two \emptyset 5 x 5 holes bored in the side of cabinet, and attach the mechanism with the five wood screws provided.






#7 x 35 mm (1-3/8") wood screws (qty 4)


3 Attach the telescopic arms



WARNING: Risk of injury from spring loaded arm.



4 Top door hinge planning




Part no.

Aluminum door hinge In-line mounting plate

72T550A 175H3100

5 Bottom door hinge planning




Part no.

Aluminum door bottom hinge Bottom door mounting plate 78Z550AT 175H5A00

Frame preparation

7 Bottom door planning



Top door height (TDH)	x
231 to 271	TDH x .5 + 70
272 to 531	TDH x .5 + 47

NOTE: 3 hinges are required for cabinet width over 1219 mm (48") or 26.5 lb. combined door weight.


Part no.

Telescopic arm mounting plate

175H5B00


8 Attach the top door to the cabinet

Determine the locations of mounting plates and hinges and attach the hardware to cabinet doors. Attach top door to the cabinet.



9 Attach the bottom door


Attach bottom door to the top door and attach the telescopic arms.




10 Finalize the tension adjustments

- 1. Close and flush doors to cabinet. Open and close door to test closing force.
- Open door and adjust tension screws on both lift mechanisms with a power drill. Test door again and repeat until desired function is achieved.

Tension adjustment should be the same on both lift mechanisms.






Use #2x2 POZI bit

11 Finalizing the door adjustments


- Adjust each top door hinge and mounting plate to properly align the top door to the cabinet.
- Adjust each bottom door hinge and mounting plate to properly align doors to the cabinet and to the top door.



NOTE: Although not illustrated here, telescopic arm mounting plates can also be adjusted horizontally $\pm\,2$ mm if needed.


12 Adjust and lock telescopic arms


- 1. Close and flush doors to cabinet. While pressing on the bottom of the top door, pull the bottom door open one inch.
- Slightly open door and lock the telescopic arms into position using the levers as shown.



13 Attach cover caps

Attach the left and right cover plates to each lift mechanism.






AWARNING

Risk of injury from spring-loaded arm


- Do not push arm assembly down or leave in the down position.
- Remove mechanism before installing or removing cabinet.

1 Removing the covers

Remove left and right cover plates.




2 Removing the door



Release both arms and gently rest the top door on the loose arms. The tension will hold the doors up for the next step.

3 Removing the doors


- 1. Hold the bottom door while unclipping the bottom hinge.
- Hold the top door while detaching the top hinges. Simply unclip them if using the CLIP top hinges or unscrew them if using COMPACT.



4 Removing the telescopic arms


Using a screwdriver, depress the release tabs to remove telescopic arms.

If transporting the cabinet to the jobsite, stop here. Lift mechanisms can stay inside the cabinet for easy transport.



*ıblum*i

Other information



Inch		mm
1/32	.031	
1/16	.063	1.5
3/32	.094	
1/8	.125	3
5/32	.156	4
3/16	.188	5
7/32	.219	5.5
1/4	.25	6
9/32	.281	7
5/16	.313	
11/32	.344	9
3/8	.375	9.5
13/32	.406	10
7/16	.438	11
15/32	.469	12
1/2	.5	13
17/32	.531	13.5
9/16	.563	14
19/32	.594	15
5/8	.625	16
21/32	.656	17
11/16	.688	17.5
23/32	.719	18
3/4	.75	19
25/32	.781	20
13/16	.813	20.5
27/32	.844	21
7/8	.875	22
29/32	.906	23
15/16	.938	24
31/32	.969	24.5
1	1	25.4

Blum, Inc. 800-438-6788 sales.us@blum.com blum.com